



GSatTrack

FM1100

GPS/GSM Terminal

FM1100 is a light terminal with GPS and GSM connectivity, which is able to get device coordinates and other data and transfer them via GSM network. This device is perfectly suitable for applications where location acquirement of remote objects is needed. So you can track your remote objects (trucks, cars etc) quickly and easily.

In case of losing connection FM1100 can store up to 8000 records, and once the connection is established the device will send stored data via GPRS. So you won't lose your data (coordinates, sensors data and etc.).

FM1100 can perform tasks on remote objects, such as monitoring engine status, controlling truck's door etc.

Small Size

Car Tracking

Parametrized Operation (acquire & send)

Integrated Scenarios

- Green Driving (Ratings Of Acceleration, Breaking, Cornering)
- Overspeeding
- Authorized Driving (50 iButton Keys)
- Immobilizer

Online Tracking

Low Energy Consumption In Deep Sleep Mode

Application

- Track and Trace
- Road Assistance
- International Logistics
- Personal Car and Van Tracking
- Fleet Management





Specifications

GSM Specifications

Quad-band 900/1800 MHz
850/1900 MHz GPRS class 10 (up to 85,6 kbps)
SMS (text/data)

GPS Specifications

NMEA, GGA, GGL, GSA, GSV, RMC, VTG protocol
compatible
65 channel GPS receiver
-161 dBm sensitivity

User Interfaces

1 Digital Input Reserved for Ignition Status Monitoring
2 Digital Inputs
1 Analog Input (10V or 30V range)
2 Digital Open-collector Outputs (connecting external relays, LED, buzzers etc.)
1-Wire® protocol
Power supply (+10...+30) V DC
2 Status LEDs
USB Port
Configuration and firmware upload (FOTA and via USB cable)
External GSM antenna (SMA connector) External GPS antenna (MCX connector)

General Specifications

GPS and I/O data acquisition
Real Time tracking
Smart algorithm of data acquisition (time, distance, angle, ignition and event based)
Sending acquired data via GPRS (TCP/IP and UDP/IP protocols)
Smart algorithm of GPRS connections (GPRS traffic saving)
Operating in roaming networks (preferred GSM providers list)
Events on I/O detection and sending via GPRS or SMS
Scheduled 24 coordinates SMS sending
5 geofence zones (rectangular or circle)
Deep Sleep mode (saving vehicle's accumulator)
FOTA (firmware updating via GPRS)
Motion sensor
Small and easy to mount case
Roaming dependant operation (GPRS traffic saving in roaming zones)
Operation mode presets:
 Advanced overspeeding detection
 Driver behavior monitoring (acceleration/breaking/cornering notification to minimize the vehicle exploitation costs)
 Driver identification (1-Wire® iButton ID key)